

GETTING YOUR OMNITUB HOME

# Door Ways

## What to check before your handmade tub arrives

A standard UK internal doorway is **720–750 mm** wide. Every Omnitub is designed to pass through — turned on its side it is only **625 mm** wide, so it slips through any doorway of **630 mm or more**. Check the narrowest point on the route before delivery day.

MINIMUM DOORWAY

**630 mm**

On its side your tub is just **625 mm** wide — that 5 mm is all it needs. Under 630 mm anywhere on the route, widen the access or plan another way in.

## Moving it through, step by step

- 1 **Wear protective gloves**  
The hand-polished Omnigel® surface is smooth, but trimmed flange edges can be sharp.
- 2 **Measure every doorway**  
Note the narrowest point on the route. 630 mm or more and it passes through; under 630 mm and it won't.
- 3 **Protect the polished face**  
Wrap the polished side and flanges in bubble wrap so the finish stays flawless in transit.
- 4 **Turn on its side, carry as two**  
On its side the tub is just 625 mm wide. Always lift and move it with two people, fully supported.

